

**Operation Instructions for PDF Temperature Data Logger SSNP-10ED**

Kindly go to site:

<http://en.yowexa.com/down.aspx?Fld=n14:14:14>

There are 2 files that need to be installed:

1. pidifix v2.0.4
2. pgraph v7.2.2.04.

After installation, two green icons are created on the desktop, called "data logger setup" and "data logger Graph". Connect the PDF data logger **SSNP-10ED** to the computer,

Click on **data logger setup** and adjust the desired temperature thresholds.

Mark the Ext mark .

Sample every as Sample interval times. i.e. 20 minutes as in chart bellow , the temperature sensor will be active for 120 days

Att: The sensor is active only if on the display says: Rec .

Att: To synchronize the logger with PC – As in chart below mark Update Report and Update Time.

After adjustment done, please press button **Configure**.

A label saying Configured Successfully should appear.

Channels

Temp.	High Limit: 8	Accumulation: <input type="checkbox"/>	Alarm Delay: 0 Min.	Low Limit: -2	Accumulation: <input type="checkbox"/>	Alarm Delay: 0 Min.	°C °F: <input checked="" type="radio"/> °C <input type="radio"/> °F	Ext: <input checked="" type="checkbox"/>
Humidity	High Limit: 75	Accumulation: <input type="checkbox"/>	Alarm Delay: 0 Min.	Low Limit: 30	Accumulation: <input type="checkbox"/>	Alarm Delay: 0 Min.	RH%: <input type="checkbox"/>	Ext: <input type="checkbox"/>

Sample Interval Time

30S  1M  2M  3M  5M  10M  15M  20M  25M  30M  1H

Others: 10 S Max. Points: 8640 Days: 120

Start Delay: 0 Min.  pdf  dlg  csv  xls  txt  LCD ON  Stop by Button  Restart

Update Report Title: DATA REPORT Trip No.: Trip Description:

Update Time: 17:13:08  Update Time Zone: UTC 8 Offset: 0 Hours

No device or file is generating

Buttons: Password... Calibration... Refresh Save as... R Read Back Configure Exit

**Release the Logger SSNP-10ED from the computer and connect the sensor.**

To activate Rec press the black button for 2-3 seconds till the "Rec" sign appears.

**Insert the external sensor to ambient / refrigerator.**

**Install the Logger SSNP-10ED outside of the refrigerator.**

**To read the data from the Logger SSNP-10ED please disconnect it from the sensor , connect to the USB drive , PDF file will appear on the the Logger SSNP-10ED drive.**

**Please download the PDF file to the desk top.**